


SCANNING A BALLOT



Feed your ballot into the tabulator.

When a valid ballot is scanned, the screen will display the messages “Casting Ballot” and “Ballot Successfully Cast”.

Once the ballot is in the ballot box, the “System Ready” screen will reappear and the “BALLOTS CAST” counter at the bottom of the screen will have increased by one.

Tabulator Warning Messages

Blank Ballot Warning	The tabulator does not detect any voter selections on the scanned ballot. Please ensure you used a proper marking pen.
Overvote Warning	One or more contests have too many votes. If you choose to cast the ballot as-is, contests with too many votes will not be counted.
Ambiguous Marks Warning	The tabulator detected marks on the ballot but the selections are not clear. The ballot will be returned automatically.